



Nighthawk Security

PO BOX 25035

Woodbury, MN 55125

help@mynighthawk.com

Phone/Fax: 1 (866) 472-3525

*****VERY IMPORTANT-SYSTEM TESTING*****

To be sure your security system is working properly the system **MUST** be tested. In order to test your system, please contact Nighthawk Security at 866-472-3525 Ext. #9 to place your system in test. You will need to provide one of the following: address, telephone number, or account number along with the password in order to have authorization. You may choose the amount of time and/or specific zone(s) you would like to test. Once the system is placed in test, please follow the steps below in order to complete testing.

1. Arm the system and trigger all the zones or the specific zones tested.
2. Once the loud sirens sounds for at least 30 seconds disarm the system using your code.
3. After disarming, you should see the zones flashing on your keypad.
4. If there are zones not displayed on the keypad, re-arm the system and trigger the missing zones.
5. Contact Nighthawk Security to verify if the zones tested were accurately received as displayed on your keypad.

You may also log on to <https://mymonitoringstation.com/> to view your event history and account information. You will need your account number and password in order to log on.

6. Contact Nighthawk Security again; make sure they receive a signal from every zone, then place the system on "2-way test". Send one more signal from any zone; wait for the operator to connect by 2-way voice.
7. To reset your system, type in your code and off consecutively 2 times.
8. System testing should be completed at minimum once a month.